



# User Guide


## Read before use

Read this guide carefully before use and keep it for future reference. Please use the lamp according to the precautions for use. Failure to do so will void the warranty. Dealer disclaims any responsibility for the incorrect use of the product or the transformer with another product which would be defective, dangerous or inappropriate.

### CHARGE

1. Plug is not provided in the set. The lamp can only be charged using the USB interface or USB power adapter.
2. The rated charging input of the lamp is DC5V/1A. Do not use the power supply with an output greater than DC5V to charge the lamp.
3. Fully charge the battery before first use. The lamp shines light red when charging; shines light blue after fully charged.
4. Do not use it near a heat source or fire.
5. Do not touch the charger while charging.
6. Disconnect the charger after charging.
7. Do not charge outdoors as most chargers are not water proof.


### INSTRUCTIONS



# LAMP

1. Do not expose lamp to fire or high temperature.
2. Do not attempt to disassemble the lamp to avoid the risk of electric shock or water damage. Failure to comply will void the warranty.
3. Avoid submerging in water and bright sunshine over extended period.
4. Product is not intended for children without adult supervision.

## REMOTE CONTROL



## WARRANTY

1. This product is under warranty for a period of six (6) months.
2. The warranty begins from the date of purchase and requires presentation of the original purchase proof to ascertain the date.
3. Replaced products or repaired parts will be warranted only for the unexpired portion of the original warranty.
4. Limited warranty does not apply to any defect resulting from negligence, accident or misuse.